

IRTC950

Thermal Imager



Content	Page
1.Introduction.....	5
2.Safety Information.....	5
3.Specifications.....	7
4.Structure Description.....	9
5.Before You Start.....	10
5-1.How to Charge the Battery.....	10
5-2.Power On.....	10
5-3.Power Off.....	11
5-4.Desktop.....	11
5-5.Lens.....	12
5-6.Focus.....	13
5-7.Shutter.....	13
5-8.LED Light.....	13
5-9.Laser.....	13
5-10.TemperatureMeasurement.....	13
5-11.Emissivity Adjustment.....	14
5-12.Reflected Temperature.....	15
5-13.Thermal Imager Reporter Software.....	15
6.Menus.....	16
6-1.Main Menu.....	16
6-2.Image Mode.....	16
6-3.Image Palette.....	19
6-4.Image Adjustment.....	20
6-4-1.Lock Operation.....	20
6-4-2.Histogram Mode and Auto Mode.....	21
6-5.Measurement Menu.....	22
6-6.Parameter Menu.....	22
6-6-1.Ambient Temperature Composition.....	23
6-6-2.Reflective Temperature.....	23
6-6-3.Atmospheric Humidity.....	24
6-6-4.Delta Temperature Compesation.....	24
6-6-5.Distance.....	24
6-6-6.Emissivity.....	25
6-7.Settings Menu.....	25
6-7-1.Device Setting.....	25
6-7-2.Measure Setting.....	28
6-7-3.Reset.....	30

Content	Page
6-8.Camera Menu.....	31
6-9.Video Menu.....	33
6-10.Files Browser.....	33
6-11.USB Mode.....	34
6-12.HDMI Output.....	34
7.Android/iOS APP InfraRead.....	35
7-1.Software Install and Uninstall.....	35
7-1-1.System Required.....	35
7-1-2.InfraRead App Install.....	35
7-2.InfraRead Function.....	35
7-2-1.Import Pictures.....	35
7-2-2.Analyze.....	35
7-2-3.Report and Share.....	37
8.PC Software.....	38
8-1.System Required.....	38
8-2.InfraRead Pro Install.....	38
8-3.Running.....	39
8-4.Uninstall.....	39
9.Fault Diagnosis and Exclusion.....	39

1.Introduction

Overview

- The Thermal Imager is handheld imaging camera used for predictive maintenance, equipment troubleshooting, and verification.
- Focus the len to the object, Then the thermal and visual images are displayed on the LCD and can be saved to a Micro SD Memory card.
- Transferring images to a PC is accomplished by removing the SD memory card and connecting it to a PC through the included card reader, or transfer the images and video stream to the smart device with "Thermoview" apps installed.
- In addition to the features mentioned above, the Thermal Imager provide video recording with audio and play back.

2.Safety Information

- To prevent eye damage and personal injury, do not look into the laser. Do not point laser directly at persons or animals or indirectly off reflective surfaces.
- Do not disassemble or do a modification to the Thermal Imager.
- Do not point the Thermal Imager (with or without the lens cover) at intensive energy sources, for example devices that emit laser radiation, or the sun.
- This can have an unwanted effect on the accuracy of the camera. It can also cause damage to the detector in the Thermal Imager.
- Do not use the Thermal Imager in a temperature higher than 50°C (122°F), lower than -20°C (-4°F), High temperature or low temperature can cause damage to the Thermal Imager.
- Only use the correct equipment to discharge the battery.
- If you do not use the correct equipment, you can decrease the performance or the life cycle of the battery, If you do not use the correct equipment, an incorrect flow of current to the battery can occur, This can cause the battery to become hot, or cause an explosion and injury to persons.
- Do not pull out the battery when the thermal imager is working.
- If you pull out the battery when the thermal imager is working, it may cause the thermal imager work unnormal.
- Do not disassemble or do a modification to the battery.
- The battery contains safety and protection devices which, if they become damaged, can cause the battery to become hot, or cause an explosion or an ignition.
- If there is a leak from the battery and the fluid gets into your eyes, do not rub your eyes, Flush well with water and immediately get medical care.
- Do not make holes in the battery with objects, Do not hit the battery with a hammer, Do not step on the battery, or apply strong impacts or shocks to it.
- Do not put the battery in or near a fire, or in direct sunlight, or other high-temperature locations, Do not solder directly onto the battery.
- Always charge the battery in the special temperature rang.
- The temperature range through which you can charge the battery is 0 to 50°C (32 to 122°F), If you charge the battery at temperatures out of this range, it can cause the battery to become hot or to break, It can also decrease the performance or the life cycle of the battery.

- Do not get water or salt water on the battery, or permit the battery to get wet.
 - Clean the case with a damp cloth and a weak soap solution. Do not use abrasives, isopropyl alcohol, or solvents to clean the case or lens/screen.
 - Be careful when you clean the infrared lens, Do not clean the infrared lens too vigorously, This can damage the anti-reflective coating.
 - Take the Thermal Imager from cold to hot, it will appear condensation in thermal Imager, To protect the Thermal Imager, you should power of the Thermal Imager, wait until the Thermal Imager has become warm enough for the condensation to evaporate.
 - If you do not use the Thermal Imager, put the Thermal Imager in cool and dry environment, if you store Thermal Imager equipped with the battery, the power of the battery will be exhausted.
- a. When the product is charging, the flashlight function cannot be used.
- b. Audio Out.

3.Specifications

Imaging and Optical Data

Field of View (FOV)/Minimum Focus Distance	17° x 12.7° / 0.5m
Spatial Resolution (IFOV)	0.77mrad
Thermal Sensitivity/NETD	<0.04°C at 30°C (86°F)/40mK
Image Frequency	25Hz
Focus Mode	Manual
Zoom	1-32x continuous, digital zoom.
Focal Length	22mm
Focal Plane Array (FPA)/Spectral Range	Uncooled microbolometer / 8-14μm
IR Resolution	384 x 288 pixels

Image Presentation

Display	3.5in. LCD, 640x480 pixels, Touch screen
Image Modes	IR image, Visual image, Picture in picture, Auto fusion, Laser distance meter with fusion.
Color Palettes	IRON, Rainbow, Grey, Grey Inverted, Brown, Blue-red, Hot-cold, Feather, Above alarm, Below alarm, Zone alarm, Vision zone

Measurement

Object Temperature Range	-20 to 150°C (-4 to 302°F) / 0 to 650°C (32 to 1202°F)
Temperature Accuracy	±2°C (±3.6°F) or ±2% of reading (Environment temperature 10 to 35°C, Object temperature >0°C).
Laser Distance Meter	0.05 to 30m (0.15 to 98ft)
Laser Distance Accuracy	Typically ±5mm (0.2in)

Measurement Analysis

Spot	Center Spot, Three manual spots
Automatic Hot/Cold Detection	Auto hot or cold markers
Line	Two lines analyse
Area	Three areas analyse
Measurement Corrections	Emissivity, Reflected temperature, Ambient temperature, Atmospheric humidity, Infrared compensation, Distance compensation

Storage of Videos

Storage Media	8Gbytes Micro SD card or 3.4GB internal EMMC
Video Storage Format	Standard MPEG-4 encode, 640x480 at 30fps, on memory card >60 minutes
Video Storage Mode	IR/visual images; simultaneous storage of IR and visual images




Storage of Images

Image Storage Format	Standard JPEG, or HIR files including measurement data, on memory card >6000 pictures
Image Storage Mode	IR/visual images; simultaneous storage of IR and visual images
Image Analyse	Internal image analyse tools, Complete function.

Set-Up	
Laser	<Class2
Set-up commands	Local adaptation of units, language, date and time formats, information of camera
Languages	Multinational
Digital Camera	
Built-in Digital Camera	5 Megapixels
Built-in Digital Lens Data	FOV 59°
Data Communication Interfaces	
Interfaces	USB-Mini, HDMI
USB	Data transform between camera and PC; Live video between camera and PC
Video Out	HDMI
Wifi	802.11, transfer images and realtime video stream
Power System	
Battery	Li-ion battery, 4 hours operating time
Input Voltage	DC 5V
Charging System	In camera (AC adapter)
Power Management	Automatic shutdown
Environmental Data	
Operating Temperature Range	-15 to 50°C (5 to 122°F)
Storage Temperature Range	-40 to 70°C (-40 to 158°F)
Humidity (Operating and Storage)	10% to 90%
Drop Test	2m
Bump	25g(IEC60068-2-29)
Vibration	2g(IEC60068-2-6)
Physical Data	
Camera Weight, Incl. Battery	<846g
Camera Size (LxWxH)	260 x 101 x 120mm

4. Structure Description

- | | |
|-----------------------------|----------------------------------|
| 1-LED Light | 10-LCD Display and Touch Screen |
| 2-Laser Pointer | 11-Focus Ring |
| 3-Laser Distance Meter Len | 12-Images Browse Button |
| 4-Visual Camera | 13-Laser Distance Measure Button |
| 5-Infrared Camera Lens | 14-Power/Lock Button |
| 6-Dust Cover Lanyard Hole | 15-Menu/Select Button |
| 7-Hole for Tripod Insertion | 16-Up/Down/Right/Left Button |
| 8-Battery | 17-Trigger |
| 9-Interface and Cover | |
| 9.1-Audio/Microphone | |
| 9.2-Micro SD Card Slot | |
| 9.3-Micro USB/Charge | |
| 9.4-HDMI | |



5. Before You Start


5-1. How to Charge the Battery

- Before you use the Thermal Imager for the first time, charge the battery for three and three-half hours.
- The battery status shows on the six-segment charge indicator.
- To charge the battery, use follow before:
 1. Connect the ac power adapter into an ac wall outlet and connect the dc output to the Thermal Imager's ac power socket, the charge light is on, The battery indicator becomes "☐ → ☐ → ☐ → ☐ → ☐ → ☐" while the battery charges with the ac power adapter.
 2. Charge until the charge indicator becomes "☐", the charge icon not changed.
 3. Disconnect ac power adapter when the battery is full charged.


Note: Make sure that the Thermal Imager is near room temperature before you connect it to the charger. Do not charge in hot or cold areas. When you charge in extreme temperature, battery capacity may be decreased.

5-2. Power On

To turn the Thermal Imager on, push the **Power/Lock** "☰ | ☐" Button about 2 seconds.



Note: After power on the device, the thermal Imager needs sufficient warm-up time for the most accurate temperature measurements and best image quality. So the visible image will first appear, and the thermal sensor will calibrate internal for several seconds. After that the thermal image will be displayed on the screen.



5-3.Power Off


- When Thermal Imagers power on, Push and hold the **Power/Lock** “ 

- Push and hold the **Power/Lock** “ 

5-4.Desktop

The Desktop is as follow:

- | | | |
|----------------------------|--------------------------------------|---|
| 1-Temperature Unit | 10-Time | 19-Centre Point Cross |
| 2-Distance Unit | 11-Image Display Area | 20-Manual adjust Max temperature of current scene with up or down key |
| 3-Emissivity | 12-Main Menu | 21-Manual adjust Min temperature of current scene with up or down key |
| 4-Zoom Quick Menu Entrance | 13-Laser Distance Meter Indicator | 22-Min Temperature of Current Scene |
| 5-Flashlight ON Status | 14-Laser Distance Meter Readings | 23-AGC Mode Select Button |
| 6-Laser ON Status | 15-Centre Point Temperature Readings | 24-Color Bar |
| 7-SD Card | 16-Video Record Status | |
| 8-WiFi ON Status | 17-AGC Mode | |
| 9-Battery Capacity Status | 18-Max Temperature of Current Scene | |




5-5.Lens

- The Thermal Imager has a Lens.
- **FOV** is the largest area that your imager can see at a set distance.
- This table lists the horizontal FOV, vertical FOV and IFOV for lens.

Focal Length	Horizontal FOV	Vertical FOV	IFOV
22mm	17°	12.7°	0.77mrad

- **IFOV** (Instantaneous Field of View) is the smallest detail within the FOV that can be detected or seen at a set distance, the unit is rad, The formula is this: **IFOV=(Pixel Size)/(Lens focal length)**.
- **D:S theoretical** (=1/IFOV theoretical) is the calculated spot size based on the pixel size of the Thermal Imager detector array and lens focal length.

Example: If Thermal Imager uses 22mm lens, because the Pixel Size of detector is 17µm, Horizontal FOV is 17°, Vertical FOV is 12.7°, the IFOV is 17µm/22mm=0.77mrad; D:S theoretical (=1/ IFOV theoretical)=1298:1.



- **D:Smeasure** (=1/IFOV measure) is the spot size needed to provide an accurate temperature measure.
- Typically D:S measure is 2 to 3 times smaller than D:S theoretical, which means the temperature measurement area of the target need to be 2 to 3 times larger than that determined by the calculated theoretical D:S.

Note: IFOV theoretical represents the smallest objects that the thermal imager can detect or see. IFOV measure represents the smallest object form which an accurate temperature can be measured by the thermal imager.

5-6.Focus

- To adjust focus, clockwise or Anti-clockwise rotates the IR Lens.
- When target comes into focus, it shows a sharper image.
- When the target moves out of focus, the thermal image becomes blurry.



Note: Correct focus is important in all imaging applications. Correct focus makes sure that the infrared energy is correctly directed onto the pixels of the detector. Without the correct focus, the thermal image can be blurry and the radiometric data will be inaccurate. Out-of-focus infrared images are frequently unusable or of little value.

5-7.Shutter

- The thermal image of the Thermal Imager becomes blurry, when the Thermal Imager no correcting after some minutes or the Thermal Imager changes target.
- To get fine thermal image, the Thermal Imager need to correct.
- The Thermal Imager has two mode for correcting, Manual and Auto mode.
- In Manual Mode, long press the down arrow button, the Thermal Imager will correct.
- In Auto Mode, the Thermal Imager can correct automatically while The thermal image of the Thermal Imager becomes blurry.

5-8.LED Light

In quick setting menu, press the flash light button, the LED light will be on or off.

5-9.Laser

- In desktop, long press the “” Button and hold about 2 seconds, the laser is on.
- In desktop, long press the “” Button and hold about 2 seconds again, the laser is off.

5-10.Temperature Measurement

- All objects radiate infrared energy.
- The quantity of energy radiated is base on the actual surface temperature and the surface emissivity of the object.
- The Thermal Imager senses the infrared energy from the surface of the object and uses this data to calculate an estimated temperature value.
- Many common objects and materials such as painted metal, wood, water, skin, and cloth are very good at radiating energy and it is easy to get relatively accurate measurements.

- For surfaces that are good at radiating energy (high emissivity), the emissivity factor is ≥ 0.90 .
- This simplification does not work on shiny surfaces or unpainted metals as they have an emissivity of <0.6 . These materials are not good at radiating energy and are classified as low emissivity.
- To more accurately measure materials with a low emissivity, an emissivity correction is necessary.
- Adjustment to the emissivity setting will usually allow the Thermal Imager to calculate a more accurate estimate of the actual temperature.
- More information please see Emissivity Adjustment to get the most accurate temperature measurements.

5-11.Emissivity Adjustment

- The correct emissivity value is important to make the most accurate temperature measurement.
- Emissivity of a surface can have a large effect on the apparent temperatures that the Thermal Imager observes.
- Understanding the emissivity of the surface, but may not always, allow you to obtain more accurate temperature measurements.

Note: Surfaces with an emissivity of <0.60 make reliable and consistent determination of actual temperature problematic. The lower the emissivity, the more potential error is associated with the Imager’s temperature measurement calculations. This is also true even when adjustments to the emissivity and reflected background adjustments are performed properly.

- Emissivity is set directly as a value or from a list of emissivity values for some common materials.
- The global emissivity displays in LCD Screen as $E=x.xx$.

The following table gives typical emissivity of important materials.

Material	Emissivity
Water	0.96
Stainless Steel	0.14
Aluminum Plate	0.09
Asphalt	0.96
Concrete	0.97
Cast Iron	0.81
Rubber	0.95
Wood	0.85
Brick	0.75
Tape	0.96
Brass Plate	0.06
Human Skin	0.98
PVC Plastic	0.93
Polycarbonate	0.80
Oxidized Copper	0.78
Rust	0.80
Paint	0.90
Soil	0.93

5-12. Reflected Temperature

- Using the offset factor, the reflection is calculated out due to the low emissivity and the accuracy of the temperature measurement with infrared instruments is improved.
- In most cases, the reflected temperature is identical to the ambient air temperature.
- Only when objects with strong emissions with much higher temperature are in the proximity of the object being measured should be determined and used.
- The reflected temperature has only little effect on objects with high emissivity.
- The reflected temperature can be set individually.
- Follow these steps to get the right value for the reflected temperature.
 1. Set the emissivity to 1.0.
 2. Adjust the optical lens to near focus.
 3. Looking in the opposite direction away from the object, take a measurement and freeze the image.
 4. Determine the average value of the image and use that value for your input of reflected temperature.

5-13. Thermal Imager Reporter Software

- Thermal Imager Reporter software is supplied with the Thermal Imager.
- This Software is intended for Thermal Imager and contains feature to analyze images, organize data and information, and make professional reports.
- Thermal Imager Reporter software allows audio annotations and commentary to be reviewed on a PC.

6. Menus

The menus, together with buttons, are access for image, measurement, Emiss, Palette, temperature measurement range, take photo and video, review, and settings.

6-1. Main Menu

- Press “Menu/OK” Button or touch the screen, the main menu will be popped up.
- Main Menu is the main interface of the Thermal Imager’s menus.
- It contains five items such as Measure parameters, Measure tools, Image mode, Palette, system Settings.



- Alarm:** Set alarm temperature.
- Parameters:** Parameters set for the calculation temperature.
- Measure Tools:** Set for the calculation and display of radiometric temperature measurement data related to the thermal images.
- Image Mode:** Set image source for the display on the Thermal Imager’s LCD. It contains five items such as infrared image, visual image and fusion.
- Palette:** Set the type of color bar.
- Settings:** Set for the user preferences such as language, unit of temperature measurement, date, time; restore factory setting and display product information.

6-2. Image Mode

1. In main menu, press “Image Mode” icon button, highlight “Image Mode”.
2. Press “Up” button, popup Image submenu which contains five image modes.
3. Press “Left” or “Right” button, or touch the image mode icons, highlight the Image mode which you want to choose.
4. The image mode will change after you choose it.




5. Thermal Imager has 6 kinds of image modes for display: IR, Camera, Fusion, AUF mode, LDM, Zoom Mode.




IR: Displays only infrared image.



Camera: Displays only visible image.



Fusion: Display fusion image of infrared and visible images.



AUF: Auto Fusion mode, compare the centre area temperature with full screen, the machine will calculate the mix ratio of infrared and visible images automatically.





 **LDM Mode:** This mode use laser distance meter to get object distance.

- In the Laser distance meter mode, it can measure the distance between the object and the device, Press the “—” button the laser will opened, and the device is ready for measure.

- Press “—” again, the distance value will displayed and the image will freeze for you to review.

- Press “OK” to save the picture, or press “—” to release the image.

 **Zoom Mode:** Set the image zoom in or zoom out.




6-3. Image Palette

- The Image Palette lets you change the false-color presentation of the infrared images on display or captured.
- A variety of palettes are available for specific applications.
- The standard palettes offer an equal, linear presentation of colors that allow for best presentation of detail.

Standard Palette

1. In main menu, press **"Palette"** icon button, highlight **"Palette"**.
2. Press **"Up"** Button, popup Image submenu which contains 8 kinds of color palettes and 4 kinds of special palettes.
3. Press **"Left"** or **"Right"** Button, or touch the image mode icons, highlight the palette which you want to choose.
4. The palette mode will be changed after you choose it.



Iron



Rainbow



White Hot



Black Hot



Brown Hot



Blue Red




Hot Cold




Feather

- Above Alarm:** The temperature higher than the high alarm set value will be colored to red, press the Hi: 30.0 value button to adjust the above temperature.




- Below Alarm:** The temperature lower than the low alarm set value will be colored to blue, press the Lo: 29.4 value button to adjust the below temperature.



 **Zone Alarm:** The temperature between the high alarm and the low alarm set value will be colored to orange.



 **Visible Zone:** The temperature between the high alarm and the low alarm set value will be colored to the palette, other part of the image will displayed as visible image.



6-4. Image Adjustment

There are three kinds of mode for image adjustment, hisgram, Auto and Manual.


6-4-1. Lock Operation

- Press **Power/Lock** “ | 

Lock the low level and adjust the high level of the temperature range:



Lock the high level and adjust the low level of the temperature range:



6-4-2.Histogram Mode and Auto Mode

- Auto Mode: level and span are decided by the thermal image of minimum temperature and maximum temperature, The relationship between temperature and color is linear.
- Histogram Mode: the thermal image is enhanced by histogram algorithm, The relationship between temperature and color is not linear, Some part of the image is enhanced.
- Touch the icon "HG" or "AUTO" below the colorbar to change the mode.



6-5.Measurement Menu

- 1.In main menu, press “**Measurement**” icon button, highlight “**Measurement**”.
- 2.Press “**Up**” button, popup Image submenu which contains 5 kinds of Measurement tools.
- 3.Press “**Left**” or “**Right**” button, or touch the Measurement tools icons, highlight the Measurement tool which you want to choose.
- 4.The Measurement tool will be enabled after you choose it.



- ✚ **Center Point:** Measure the center point temperature.
- ✚ **Measure Point:** Measure the manual point temperature, There are three manual analyse points.
- 💡 **Hi/Lo Spot Analyse:** Capture max/minimum temperature.
- 📐 **Area Analyse:** Measure the area temperature, There are three analyse areas.
- 📏 **Line Analyse:** Measure the line temperature, There are two analyse lines, One for horizontal, the other is vertical line.
- 🗑️ **Delete all Analyse:** Delete all analyse tools.

6-6.Parameter Menu

In main menu, press “**Up**” and “**Down**” button, highlight “**Emiss**”, press “**Select**” button, popup object parameter submenu.



6-6-1.Ambient Temperature Composition

- In Ambient temperature submenu, press “Left” and “Right” arrow to change the temperature values.
- Ambient temperature will affect the measurement of the thermal imager, it can be composite from -10 to 50 degree.



6-6-2.Reflective Temperature

- In reflective temperature submenu, press “Left” and “Right” arrow to change the temperature values.
- The reflective temperature is important for radiometric temperature measurement, Thermal Imager has temperature compensation for reflective temperature.
- To get more accurate temperature measurement, accurately set the reflective temperature.
- In most cases, the reflected temperature is identical to the ambient temperature.
- Only when objects with strong emissions with much higher temperature are in the proximity of the object being measured, the reflected temperature must set.



6-6-3. Atmospheric Humidity

- In Atmospheric humidity submenu, press “**Left**” and “**Right**” arrow to change the temperature values.
- Water droplets in the air can absorb infrared rays, The wet air can affect the measurement of the temperature’s accurate, the compensation humidity can be set from 0%~100%.



6-6-4. Delta Temperature Compensation

In delta temperature submenu, press “**Left**” and “**Right**” arrow to change the temperature values.




6-6-5. Distance

- In distance submenu, press “**Left**” and “**Right**” arrow to change the distance values.
- There are many substances in the air that can absorb infrared rays, So the infrared ray of the object will decayed as the distance increase.
- The distance can be setted from 0 to 2000 meters.




6-6-6.Emissivity

- In emissivity submenu, press “**Left**” and “**Right**” arrow to change the emissivity values.
- “**Emiss**” sets object emissivity, the value range is 0.01~1.00.





6-7.Settings Menu

- 1.In main menu, press “**Settings**” icon button, highlight “**Settings**”.
- 2.The Settings menu will display.



6-7-1.Device Setting

There are multipages in Device setting, use “**✓**” icon to go to next page, or use “**^**” to go to previous page.



USB Mode:

- **PC Connection:** Set the device as Mass storage mode, if connect the device to the PC with USB cable, there will be a Mass storage device on the PC.
- **PC Camera:** Set the device as UVC camera mode, if connect the device to the PC with USB cable, there will be a UVC camera device on the PC.

Flashlight: Press “” → “” on the flash light. **Laser:** Press “” → “” to turn on the laser.





HDMI: Press “” → “” to turn on the HDMI output.

Brightness: Drag the slider bar to adjust the LCD brightness.


WIFI:

- Press “” → “” to turn on the wifi, the wifi model worked on access mode, so it is need to set the SSID and Password to allow other device connect to it.
- The default SSID is “xxxxxxx”, the default password is “12345678”.

Time Date : Press “” or “” to change time/date, then press “Set Date” to save the change, or press “Cancel” to quit.




Language: Press “Up/Down” Button to select language and use “MENU/OK” Button to set selected language to be valid.



Auto Power Off

- There are four options in auto power off menu, as follows: “OFF”, “5Min”, “10Min”, “15Min”, “30Min”.
- When press the touch screen or keyboard, the timer of Auto Power Off will be cleared and re-timed.




About: The info menu contains all of the product information, such as: Software Version, Serial Number and so on.




6-7-2.Measure Setting

Thera are four options in Measure setting menu, as follow picture.




Distance Unit

- Change the distance unit between “m” and “ft”, “m” means meter, ft means Foot.
- 1(ft)=0.3048(m); 1(m)=3.2808399(ft).




Temperature Unit

- Temperature Unit have three types to choose: °C, °F and K.
- Conversion relationship: °F=1.8 x °C+32, K=273.15+°C.



Temperature Range

- The temperature measurement ranges have “-20~150°C” and “0~650°C” to choose.
- The overlap temperature of the two ranges is more accurate to choose “-20~150°C”.



Emissivity: Quick set the emissivity from the table below:


Material	Emissivity	Material	Emissivity	Material	Emissivity
Water	0.96	Rubber	0.95	PVC Plastic	0.93
Stainless Steel	0.14	Wood	0.85	Polycarbonate	0.80
Aluminum Plate	0.09	Brick	0.75	Oxidized Copper	0.78
Asphalt	0.96	Tape	0.96	Rust	0.80
Concrete	0.97	Brass Plate	0.06	Paint	0.90
Cast Iron	0.81	Human Skin	0.98	Soil	0.93

Alarm Mode


- **OFF:** Turn off the alarm display and sound.
- **Above Alarm:** If the temperature of the object exceeds the above alarm value, there will be alarm sound and display.
- **Below Alarm:** If the temperature of the object below the low alarm value, there will be alarm sound and display.
- **Zone Alarm:** If the temperature of the object between the low alarm value and the above alarm value, there will be alarm sound and display.

Image Align


- Press “< > ^ v” to adjust the vision’s position to align the vision and infrared.
- Press “X” to cancel the setting, press “✓” to save the alignment setting.



6-7-3.Reset




Format Memory: Format Memory operation will format all the Picture Gallery, the device setting is not affected.



Factory Settings

Factory Settings of the Thermal Imager is as follow:

Item	Parameter	Value
Measurement	Center Spot Measurement	off
	Hot Spot Measurement	off
	Cold Spot Measurement	off
Measurement Parameters	Emissivity	0.95
	Reflective Temperature	25°C
Image	Mode	Infrared
	Palette	Iron
	Adjustment	Auto
System Setting	Language	English
	HDMI Output	off
	Laser	off
	Lamp	off



6-8.Camera Menu

- Thermal Imager has photo and video functions.
- In photo function, the Imager can save thousands of images.
- Every image resolution is 1280x960, format is ".jpg", and stores infrared data and visible data in an image.
- In video function, the Imager has ".mp4" video capture for hours, and save infrared data in ".mp4" format.

Note: Images and video files are stored in SD Memory Card, Images can easily be read and second analyzed within Thermal Imager PC software.

Save Image

- 1.In desktop, press Trigger button, freeze an image, the save menu will display.
- 2.Press **"Menu/ok"** key save image, and the image will flash for a second, after the image is saved, the image will be unfreeze.



Add Voice Recording

Touch the "Recording" icon, it can add voice information into the picture.



Add Text Note

- Touch the "Text information" icon, it can add some text information into the picture.
- Next time if the saved picture opened in gallery or PC software, the text info will displayed with the picture.



Change Measure Parameters

Touch the “Parameters” icon, it can change the image’s measure parameters: Emissivity, Ambient Temperature, Humidity, Reflect Temperature, Infrared Compensation, Distance.



Add Analyse Tools

Touch the “Measurement” icon, it can add or change the analyse tools in the image: Point Analyse, Area Analyse, Line Analyse.



Change Image Mode

Touch the “Image mode” icon, it can change the image mode: Thermal, Visible, Picture in Picture, Auto Fusion, Zoom.



Change Color


Touch the “Pallete” icon, it can change the image color.



6-9.Video Menu


The Thermal Imager has “.mp4” video capture.

- 1.In desktop, press Trigger button and hold for about 2 seconds, start video capture with voice.
- 2.To stop video capture, press Trigger button again, the video saved in the video file.



6-10.Files Browser

In desktop, press “Files Browse” button, popup files Browser, Which displays images and videos saved in SD Memory Card.



Analyse an Image

When current file type is image, press “” to enter image analysis mode.

Play a Video


When current file type is video, press “” to play video.

Delete a File

press “” to delete the current file.

6-11.USB Mode

- Connect USB cable to device, popup the menu as follow:
- There are two modes for USB, Storage and PC Camera.
- Press up or down button to switch mode.



6-12.HDMI Output

- The video output available in the Thermal Imager enables displaying the thermal image (Not includes operator menu) on an external monitor or video recording device capable of managing HDMI systems.
- To connect the Thermal Imager, proceed as follows:
 - 1.Connect the Thermal Imager to the external HDMI monitor or recording device using the HDMI video cable provided.
 - 2.Turn on the external HDMI monitor or device.
 - 3.Power on the Thermal Imager.
 - 4.With the image displayed on the external HDMI monitor or device, the thermal imager's display works simultaneously.
 - 5.Once the operations on the external device are finished, Switch off the extern device and disconnect the HDMI video cable from the thermal imager.

7.Android/iOS APP InfraRead

7-1.Software Install and Uninstall

7-1-1.System Required

Android mobile phone: Android 4.0 above, with USB OTG Support

iOS: iPhone4 above



InfraREAD

7-1-2.InfraRead App Install

Android: Search "Thermview" on Google Play and install it.



iOS: Search "Thermview" on Apple Store and install it.

7-2.InfraRead Function

7-2-1.Import Pictures

1.Use the USB OTG cable download the IR pictures from the thermal imager directly.

2.Copy the IR pictures from PC or SD card.



7-2-2.Analyse

Select a IR Picture and click "🔍" icon to analyse it.




1. Image Mode

Click “” icon to select image mode, there are four mode for you to select.

- (1)  IR Mode: only infrared picture displayed.
- (2)  Visible Mode: only visible picture displayed.
- (3)  IR Fusion Mode: The infrared picture is fusioned with visible picture.
- (4)  Visible Fusion Mode: full screen fusion, the visible picture is fusioned with infrared picture.

2. Colorbar Select

Click “” icon to select colorbar. There are eight colorbar for you choice.



3. Analyze

Click “” icon to analyze the IR pictures. There are three analyze tools:



- (1)  Point Analysis: Add a point to the picture, it will display the temperature of the point.
- (2)  Line Analysis: Add a line to the picture, it will display the highest, lowest and average temperature of the line.
- (3)  Area Analysis: Add a rectangle to the picture, it will display the highest, lowest and average temperature of the rectangle.

4. Save and Exit

Click “↶” to save and return to the main page of the APP.

7-2-3. Report and Share


1.Report

Click “



2.Share

Click “




8.PC Software

8-1.System Required


- Window 10 or higher version of Windows system.
- Please make sure you have installed Net Framework 4.6 when you install Thermview Pro software.
- If not, please find and install our Microsoft.NET_Framework_v4.6.exe that provided to you .
- Ppen the net framework 4.6, Follow all tips to install Net Framework 4.6 till it finishes.
- If your system already have installed Net Framework 4.6, then no need to install again.

8-2.InfraRead Pro Install

- You can insert your installation CD to install directly if you have one, or you can run "setup.exe" to install it as follow.
- Click "Next" to install, till finish installation.




- Installation Successful after click "Finish" like above.





8-3. Running

After ensuring **Infrared** software has been installed, click shortcuts on the desktop to run the software.



8-4. Uninstall

- Uninstall Thermview Pro in the Installation directory as follow.
- Run “uninst.exe” and then click “YES” to start to uninstall, and finally choose whether to reboot the computer.



9. Fault Diagnosis and Exclusion

- If you encounter any problems while using the thermal imager, overhaul according to the following table.
- If the problem persists, disconnect the power and contact with the company's technical support department.

Phenomenon of the fault	Cause of the fault	Solution
Thermal imager cannot start	No battery	Inserting the battery
	No power	Replace the battery or charge it
Thermal imager shut down	No power	Replace the battery or charge it
No Thermal image	The lens cap cover	Opened the lens cap

WARRANTY STATEMENT

Triplett Test Equipment offers a one-year warranty to the original purchaser of its products. We guarantee that our products will be free from defects in workmanship and materials for one (1) year from the purchase date.

This warranty does not cover:

- Products purchased from unauthorized distributors.
- Items that have been repaired or altered by unauthorized individuals.
- Damage from misuse, abuse, misapplication, negligence, or accidents.
- Products with altered, defaced, or removed serial numbers.
- Accessories, including batteries.

Copyright © 2024

Triplett www.triplett.com